



ENERGIZE RECEIVER

RECEIVE

DATA CHUNKS

**TRANSMIT** 

**INSERT INDEX** 

**BLOCKS INTO** 

ONLY FOR TIME(S) ASSOCIATED WITH

DESIRED PROGRAM

DEENERGIZE

RECEIVER AT

ELAPSE OF PERIOD

UNTIL NEXT TIME

OVERALL FLOW FIG. 4